



### CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S

Part Number: CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S  
 Schurter  
 SWITCH PUSHBUTTON SPST 100MA 42V  
 Datasheets: [CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S.pdf](#)  
 Lead free / RoHS Compliant  
 DHL/Fedex/TNT/UPS/EMS

**REQUEST FOR QUOTATION**

### CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S

PART NUMBER	CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S
	Schurter
	SWITCH PUSHBUTTON SPST 100MA 42V
ROHS	Lead free / RoHS Compliant
	<a href="#">CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S.pdf</a>
VOLTAGE RATING-DC	60V
VOLTAGE RATING-AC	42V
	Capacitive, Illuminated
	Wire Leads
FUNCTION SWITCH	Off-On
SERIES	CPS
PANEL CUTOUT DIMENSIONS	Circular - 19.10mm Dia
	Bulk
OPERATING TEMPERATURE	-40°C ~ 60°C
MOUNTING TYPE	Panel Mount, Front
(MSL)	1 (Unlimited)
	-
ROHS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP67 - Dust Tight, Waterproof
( )	5 ~ 28 VDC
,	LED, Cyan/Green
	Finger Guide, S Symbol
	-
	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
CURRENT RATING	100mA (AC/DC)
COLOR-ACTUATOR / CAP	Silver
	SPST
	Round, Button, Flush

#### Related Tags

Schurter CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S	CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S	CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S
CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S	CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S	CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S
CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S PDF	CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S Datasheet	CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S
CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S	CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S	Schurter CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S
Schurter CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S	Schurter	Schurter
Schurter CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S	Schurter Inc. CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S	

<p><b>CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1018-S</b>                  : Schurter                  : SWITCH PUSHBUTTON SPST 100MA 42V                  : Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1023-S</b>                  : Schurter                  : SWITCH PUSHBUTTON SPST 100MA 42V                  : Out stock</p> <p><b>RFQ</b></p>
<p><b>CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1020-S</b>                  : Schurter                  : SWITCH PUSHBUTTON SPST 100MA 42V                  : Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1014-S</b>                  : Schurter                  : SWITCH PUSHBUTTON SPST 100MA 42V                  : Out stock</p> <p><b>RFQ</b></p>
<p><b>CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1016-S</b>                  : Schurter                  : SWITCH PUSHBUTTON SPST 100MA 42V                  : Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1025-S</b>                  : Schurter                  : SWITCH PUSHBUTTON SPST 100MA 42V                  : Out stock</p> <p><b>RFQ</b></p>
<p><b>CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1013-S</b>                  : Schurter                  : SWITCH PUSHBUTTON SPST 100MA 42V                  : Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1022-S</b>                  : Schurter                  : SWITCH PUSHBUTTON SPST 100MA 42V                  : Out stock</p> <p><b>RFQ</b></p>
<p><b>CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1015-S</b>                  : Schurter                  : SWITCH PUSHBUTTON SPST 100MA 42V                  : Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1021-S</b>                  : Schurter                  : SWITCH PUSHBUTTON SPST 100MA 42V                  : Out stock</p> <p><b>RFQ</b></p>
<p><b>CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1017-S</b>                  : Schurter                  : SWITCH PUSHBUTTON SPST 100MA 42V                  : Out stock</p> <p><b>RFQ</b></p>	<p><b>CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1024-S</b>                  : Schurter                  : SWITCH PUSHBUTTON SPST 100MA 42V                  : Out stock</p> <p><b>RFQ</b></p>