



### CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S

Part Number: CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S  
 ຜູ້ຜະລິດ / ຍີ່ຫໍ້: Schurter  
 ລາຍລະອຽດສິນຄ້າ: SWITCH PUSHBUTTON SPST 100MA 42V  
 Datasheets: [PDF CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S.pdf](#)  
 ສະຖານະຂອງ RoHS: Lead free / RoHS Compliant  
 ເຮືອາາກ: ສິງກັງ  
 ເສັ້ນທາງຂົນສົ່ງ: DHL/Fedex/TNT/UPS/EMS

[REQUEST FOR QUOTATION](#)

ຮູບພາບອາດຈະເປັນຕົວແທນ.  
 ເບິ່ງຂໍ້ກຳນົດສຳລັບລາຍລະອຽດຜະລິດຕະພັນ.

#### ຂໍ້ມູນຈຳເພາະຂອງ CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S

PART NUMBER	CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S
ຜູ້ຜະລິດ	Schurter
ລາຍລະອຽດ	SWITCH PUSHBUTTON SPST 100MA 42V
ສະຖານະຂອງສະຖານະ / ສະຖານະ ROHS	Lead free / RoHS Compliant
ແຜ່ນຂໍ້ມູນ	<a href="#">PDF CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S.pdf</a>
VOLTAGE RATING-DC	60V
VOLTAGE RATING-AC	42V
ປະເພດ	Capacitive, Illuminated
ແບບສັນສຸດ	Wire Leads
FUNCTION SWITCH	Off-On
SERIES	CPS
PANEL CUTOUT DIMENSIONS	Circular - 22.10mm Dia
ການຫຸ້ມຫໍ່	Bulk
OPERATING TEMPERATURE	-40°C ~ 60°C
MOUNTING TYPE	Panel Mount, Front
ລະດັບຄວາມອ່ອນແອຄວາມຊຸ່ມຊື່ນ (MSL)	1 (Unlimited)
ຊີວິດກິນຈັກ	-
ສະຖານະຂອງສະຖານະ / ສະຖານະ ROHS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP67 - Dust Tight, Waterproof
ແຮງດັນໄຟຟ້າ (ຊີ້)	5 ~ 28 VDC
ປະເພດສະຫວ່າງ, ສີ	LED, Red/White
ຄຸນລັກສະນະ	Ceramic Actuator, Finger Guide, CTRL Symbol
ຊີວິດໄຟຟ້າ	-
ລາຍລະອຽດລາຍລະອຽດ	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
CURRENT RATING	100mA (AC/DC)
COLOR-ACTUATOR / CAP	Clear (White Filter/Diffuser)
ວົງຈອນ	SPST
ປະເພດກະແສໄຟຟ້າ	Round, Button, Flush

#### Related Tags

Schurter CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S	ຕົວແທນ ຈຳ ໜ່າຍ CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S	ຜູ້ສະ ໜອງ CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S
ລາຄາ CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S	ຮູບ CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S	ຮູບພາບ CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S
ເອກະສານຂໍ້ມູນ CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S PDF	CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S ຕາວໂຫລດ Datasheet	ເອກະສານຂໍ້ມູນ CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S
ຫຼັກ CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S	ຊື່ CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S	ຊື່ Schurter CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S
Schurter CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S	ຜູ້ສະ ໜອງ Schurter	ຕົວແທນ ຈຳ ໜ່າຍ Schurter
Schurter CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S	Schurter Inc. CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1053-S	

#### ຜະລິດຕະພັນທີ່ກ່ຽວຂ້ອງ

<p><b>CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1052-S</b>                  ຜູ້ຜະລິດ: Schurter                  ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V                  ໃນສາງ: Out stock</p> <p><a href="#">RFQ</a></p>	<p><b>CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1056-S</b>                  ຜູ້ຜະລິດ: Schurter                  ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V                  ໃນສາງ: Out stock</p> <p><a href="#">RFQ</a></p>
<p><b>CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1055-S</b>                  ຜູ້ຜະລິດ: Schurter                  ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V                  ໃນສາງ: Out stock</p> <p><a href="#">RFQ</a></p>	<p><b>CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1054-S</b>                  ຜູ້ຜະລິດ: Schurter                  ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V                  ໃນສາງ: Out stock</p> <p><a href="#">RFQ</a></p>
<p><b>CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1049-S</b>                  ຜູ້ຜະລິດ: Schurter                  ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V                  ໃນສາງ: Out stock</p> <p><a href="#">RFQ</a></p>	<p><b>CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1058-S</b>                  ຜູ້ຜະລິດ: Schurter                  ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V                  ໃນສາງ: Out stock</p> <p><a href="#">RFQ</a></p>
<p><b>CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1050-S</b>                  ຜູ້ຜະລິດ: Schurter                  ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V                  ໃນສາງ: Out stock</p> <p><a href="#">RFQ</a></p>	<p><b>CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1059-S</b>                  ຜູ້ຜະລິດ: Schurter                  ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V                  ໃນສາງ: Out stock</p> <p><a href="#">RFQ</a></p>
<p><b>CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1048-S</b>                  ຜູ້ຜະລິດ: Schurter                  ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V                  ໃນສາງ: Out stock</p> <p><a href="#">RFQ</a></p>	<p><b>CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1051-S</b>                  ຜູ້ຜະລິດ: Schurter                  ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V                  ໃນສາງ: Out stock</p> <p><a href="#">RFQ</a></p>
<p><b>CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1057-S</b>                  ຜູ້ຜະລິດ: Schurter                  ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V                  ໃນສາງ: Out stock</p> <p><a href="#">RFQ</a></p>	<p><b>CPS22-LA00A10-SNCCWTWF-AI0RWVAR-W1047-S</b>                  ຜູ້ຜະລິດ: Schurter                  ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V                  ໃນສາງ: Out stock</p> <p><a href="#">RFQ</a></p>