

**Schurter**

## CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S

Part Number:	CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S
ຜູ້ຜະລິດ / ຍີ່ຫໍ້:	Schurter
ລາຍລະອຽດສິນຄ້າ	SWITCH PUSHBUTTON SPST 100MA 42V
Datasheets:	CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S.pdf
ສະຖານະຂອງ RoHS	Lead free / RoHS Compliant
ເຮືອຈາກ	ຈີງກິງ
ເສັ້ນທາງຂົນສົ່ງ	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION

ຮູບພາບອາດຈະເປັນຕົວແທນ.  
ເບິ່ງຂໍ້ກຳນົດສຳລັບລາຍລະອຽດຜະລິດຕະພັນ.

### ຂໍ້ມູນຈຳເພາະຂອງ CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S

PART NUMBER	CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S
ຜູ້ຜະລິດ	Schurter
ລາຍລະອຽດ	SWITCH PUSHBUTTON SPST 100MA 42V
ສະຖານະຂອງສະຖານະ / ສະຖານະ ROHS	Lead free / RoHS Compliant
ແຜ່ນຂໍ້ມູນ	CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S.pdf
VOLTAGE RATING-DC	60V
VOLTAGE RATING-AC	42V
ປະເພດ	Capacitive, Illuminated
ແບບສັນສຸດ	Wire Leads
FUNCTION SWITCH	Off-On
SERIES	CPS
PANEL CUTOUT DIMENSIONS	Circular - 22.10mm Dia
ການຫຸ້ມຫໍ່	Bulk
OPERATING TEMPERATURE	-40°C ~ 60°C
MOUNTING TYPE	Panel Mount, Front
ລະດັບຄວາມອ່ອນແອຄວາມຊຸ່ມຊື່ນ (MSL)	1 (Unlimited)
ຊີວິດກິນຈັກ	-
ສະຖານະຂອງສະຖານະ / ສະຖານະ ROHS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP67 - Dust Tight, Waterproof
ແຮງດັນໄຟຟ້າ (ຊີ້)	5 ~ 28 VDC
ປະເພດສະຫວ່າງ, ສີ	LED, White/Magenta
ຄຸນລັກສະນະ	Arrow Symbol
ຊີວິດໄຟຟ້າ	-
ລາຍລະອຽດລາຍລະອຽດ	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
CURRENT RATING	100mA (AC/DC)
COLOR-ACTUATOR / CAP	Silver
ວົງຈອນ	SPST
ປະເພດກະແສໄຟຟ້າ	Round, Button, Flush

### Related Tags

Schurter CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S	ຕົວແທນ ຈຳ ໜ່າຍ CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S	ຜູ້ສະ ໜອງ CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S
ລາຄາ CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S	ຮູບ CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S	ຮູບພາບ CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S
ເອກະສານຂໍ້ມູນ CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S PDF	CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S ຕາວໂຫລດ DataSheet	ເອກະສານຂໍ້ມູນ CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S
ຜູ້ນ CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S	ຊື່ CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S	ຊື່ Schurter CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S
Schurter CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S	ຜູ້ສະ ໜອງ Schurter	ຕົວແທນ ຈຳ ໜ່າຍ Schurter
Schurter CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S	Schurter Inc. CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1048-S	

### ຜະລິດຕະພັນທີ່ກ່ຽວຂ້ອງ

<p><b>CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1053-S</b></p> <p>ຜູ້ຜະລິດ: Schurter ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V ໃນສາງ: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; border-radius: 5px;">RFQ</p>	<p><b>CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1049-S</b></p> <p>ຜູ້ຜະລິດ: Schurter ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V ໃນສາງ: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; border-radius: 5px;">RFQ</p>
<p><b>CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1043-S</b></p> <p>ຜູ້ຜະລິດ: Schurter ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V ໃນສາງ: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; border-radius: 5px;">RFQ</p>	<p><b>CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1042-S</b></p> <p>ຜູ້ຜະລິດ: Schurter ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V ໃນສາງ: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; border-radius: 5px;">RFQ</p>
<p><b>CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1044-S</b></p> <p>ຜູ້ຜະລິດ: Schurter ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V ໃນສາງ: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; border-radius: 5px;">RFQ</p>	<p><b>CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1054-S</b></p> <p>ຜູ້ຜະລິດ: Schurter ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V ໃນສາງ: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; border-radius: 5px;">RFQ</p>
<p><b>CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1047-S</b></p> <p>ຜູ້ຜະລິດ: Schurter ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V ໃນສາງ: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; border-radius: 5px;">RFQ</p>	<p><b>CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1052-S</b></p> <p>ຜູ້ຜະລິດ: Schurter ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V ໃນສາງ: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; border-radius: 5px;">RFQ</p>
<p><b>CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1045-S</b></p> <p>ຜູ້ຜະລິດ: Schurter ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V ໃນສາງ: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; border-radius: 5px;">RFQ</p>	<p><b>CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1050-S</b></p> <p>ຜູ້ຜະລິດ: Schurter ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V ໃນສາງ: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; border-radius: 5px;">RFQ</p>
<p><b>CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1046-S</b></p> <p>ຜູ້ຜະລິດ: Schurter ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V ໃນສາງ: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; border-radius: 5px;">RFQ</p>	<p><b>CPS22-LA00A10-SNCSNCF-RI0WMVAR-W1051-S</b></p> <p>ຜູ້ຜະລິດ: Schurter ລາຍລະອຽດ: SWITCH PUSHBUTTON SPST 100MA 42V ໃນສາງ: Out stock</p> <p style="text-align: center; background-color: #0056b3; color: white; padding: 5px; border-radius: 5px;">RFQ</p>