

The image shows the Schurter logo, which consists of a stylized 'S' icon followed by the word 'SCHURTER' in a bold, blue, sans-serif font. Below this, the words 'ELECTRONIC COMPONENTS' are written in a smaller, blue, sans-serif font. At the bottom of the image, there is a decorative horizontal bar composed of a series of small, gray squares of varying heights, creating a pixelated or digital effect.

CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S

Part Number:

CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S

SWITCH PUSHBUTTON SPST 100MA 42V


















Lead free / RoHS Compliant

DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION

CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S	
PART NUMBER	CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S
	Schurter
	SWITCH PUSHBUTTON SPST 100MA 42V
	Lead free / RoHS Compliant
	PDF CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S.pdf
VOLTAGE RATING-DC	60V
VOLTAGE RATING-AC	42V
	Capacitive, Illuminated
	Wire Leads
FUNCTION SWITCH	Off-On
SERIES	CPS
PANEL CUTOOUT DIMENSIONS	Circular - 22.10mm Dia
	Bulk
OPERATING TEMPERATURE	-40°C ~ 60°C
MOUNTING TYPE	Panel Mount, Front
	1 (Unlimited)
	-
	Lead free / RoHS Compliant
INGRESS PROTECTION	IP67 - Dust Tight, Waterproof
	5 ~ 28 VDC
	LED, White/Blue
	Ceramic Actuator, ON/OFF Symbol
	-
	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
CURRENT RATING	100mA (AC/DC)
COLOR-ACTUATOR / CAP	Clear (White Filter/Diffuser)
	SPST
	Round, Button, Flush

Related Tags

Schurter CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S	 CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S	 CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S
 CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S	 CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S	 CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S
 CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S PDF	CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S  Datasheet	 CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S
  CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S	 CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S	 Schurter CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S
Schurter CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S	  Schurter	   Schurter
Schurter CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S	Schurter Inc. CPS22-LA00A10-SNCCWTNF-AI0WBVAR-W1071-S	

<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS22-LA00A10-SNCCWTNF-AIOWBVAR-W1077-S</div> <div><div></div>: Schurter <div></div>: SWITCH PUSHBUTTON SPST 100MA 42V <div></div>: Out stock</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS22-LA00A10-SNCCWTNF-AIOWBVAR-W1068-S</div> <div><div></div>: Schurter <div></div>: SWITCH PUSHBUTTON SPST 100MA 42V <div></div>: Out stock</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS22-LA00A10-SNCCWTNF-AIOWBVAR-W1065-S</div> <div><div></div>: Schurter <div></div>: SWITCH PUSHBUTTON SPST 100MA 42V <div></div>: Out stock</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS22-LA00A10-SNCCWTNF-AIOWBVAR-W1075-S</div> <div><div></div>: Schurter <div></div>: SWITCH PUSHBUTTON SPST 100MA 42V <div></div>: Out stock</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS22-LA00A10-SNCCWTNF-AIOWBVAR-W1067-S</div> <div><div></div>: Schurter <div></div>: SWITCH PUSHBUTTON SPST 100MA 42V <div></div>: Out stock</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS22-LA00A10-SNCCWTNF-AIOWBVAR-W1070-S</div> <div><div></div>: Schurter <div></div>: SWITCH PUSHBUTTON SPST 100MA 42V <div></div>: Out stock</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS22-LA00A10-SNCCWTNF-AIOWBVAR-W1073-S</div> <div><div></div>: Schurter <div></div>: SWITCH PUSHBUTTON SPST 100MA 42V <div></div>: Out stock</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS22-LA00A10-SNCCWTNF-AIOWBVAR-W1074-S</div> <div><div></div>: Schurter <div></div>: SWITCH PUSHBUTTON SPST 100MA 42V <div></div>: Out stock</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS22-LA00A10-SNCCWTNF-AIOWBVAR-W1072-S</div> <div><div></div>: Schurter <div></div>: SWITCH PUSHBUTTON SPST 100MA 42V <div></div>: Out stock</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS22-LA00A10-SNCCWTNF-AIOWBVAR-W1069-S</div> <div><div></div>: Schurter <div></div>: SWITCH PUSHBUTTON SPST 100MA 42V <div></div>: Out stock</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS22-LA00A10-SNCCWTNF-AIOWBVAR-W1076-S</div> <div><div></div>: Schurter <div></div>: SWITCH PUSHBUTTON SPST 100MA 42V <div></div>: Out stock</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS22-LA00A10-SNCCWTNF-AIOWBVAR-W1066-S</div> <div><div></div>: Schurter <div></div>: SWITCH PUSHBUTTON SPST 100MA 42V <div></div>: Out stock</div> <div>RFQ</div>