



CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S

Part Number: CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S
 Schurter
 SWITCH PUSHBUTTON SPST 100MA 42V
[CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S.pdf](#)
 Lead free / RoHS Compliant
 DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION

CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S

PART NUMBER	CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S
	Schurter
	SWITCH PUSHBUTTON SPST 100MA 42V
/ ROHS	Lead free / RoHS Compliant
	CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S.pdf
VOLTAGE RATING-DC	60V
VOLTAGE RATING-AC	42V
	Capacitive, Illuminated
	Wire Leads
FUNCTION SWITCH	Off-On
SERIES	CPS
PANEL CUTOUT DIMENSIONS	Circular - 19.10mm Dia
	Bulk
OPERATING TEMPERATURE	-40°C ~ 60°C
MOUNTING TYPE	Panel Mount, Front
(MSL)	1 (Unlimited)
	-
/ ROHS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP67 - Dust Tight, Waterproof
()	5 ~ 28 VDC
,	LED, Red/Green
	P Symbol
	-
	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
CURRENT RATING	100mA (AC/DC)
COLOR-ACTUATOR / CAP	Silver
	SPST
	Round, Button, Flush

Related Tags

Schurter CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S	CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S	CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S
CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S	CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S	CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S
CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S PDF	CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S Datasheet	CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S
CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S	CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S	Schurter CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S
Schurter CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S	Schurter	Schurter
Schurter CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S	Schurter Inc. CPS19-LA00A10-SNCSNCF-RIORGVAR-W1016-S	

<p>CPS19-LA00A10-SNCSNCF-RIORGVAR-W1017-S : Schurter : SWITCH PUSHBUTTON SPST 100MA 42V : Out stock</p> <p>RFQ</p>	<p>CPS19-LA00A10-SNCSNCF-RIORGVAR-W1020-S : Schurter : SWITCH PUSHBUTTON SPST 100MA 42V : Out stock</p> <p>RFQ</p>
<p>CPS19-LA00A10-SNCSNCF-RIORGVAR-W1022-S : Schurter : SWITCH PUSHBUTTON SPST 100MA 42V : Out stock</p> <p>RFQ</p>	<p>CPS19-LA00A10-SNCSNCF-RIORGVAR-W1012-S : Schurter : SWITCH PUSHBUTTON SPST 100MA 42V : Out stock</p> <p>RFQ</p>
<p>CPS19-LA00A10-SNCSNCF-RIORGVAR-W1014-S : Schurter : SWITCH PUSHBUTTON SPST 100MA 42V : Out stock</p> <p>RFQ</p>	<p>CPS19-LA00A10-SNCSNCF-RIORGVAR-W1013-S : Schurter : SWITCH PUSHBUTTON SPST 100MA 42V : Out stock</p> <p>RFQ</p>
<p>CPS19-LA00A10-SNCSNCF-RIORGVAR-W1015-S : Schurter : SWITCH PUSHBUTTON SPST 100MA 42V : Out stock</p> <p>RFQ</p>	<p>CPS19-LA00A10-SNCSNCF-RIORGVAR-W1018-S : Schurter : SWITCH PUSHBUTTON SPST 100MA 42V : Out stock</p> <p>RFQ</p>
<p>CPS19-LA00A10-SNCSNCF-RIORGVAR-W1021-S : Schurter : SWITCH PUSHBUTTON SPST 100MA 42V : Out stock</p> <p>RFQ</p>	<p>CPS19-LA00A10-SNCSNCF-RIORGVAR-W1019-S : Schurter : SWITCH PUSHBUTTON SPST 100MA 42V : Out stock</p> <p>RFQ</p>
<p>CPS19-LA00A10-SNCSNCF-RIORGVAR-W1010-S : Schurter : SWITCH PUSHBUTTON SPST 100MA 42V : Out stock</p> <p>RFQ</p>	<p>CPS19-LA00A10-SNCSNCF-RIORGVAR-W1011-S : Schurter : SWITCH PUSHBUTTON SPST 100MA 42V : Out stock</p> <p>RFQ</p>